

YTQY - Torquay Airport

325 Blackgate Rd. Torquay

POWER LINES




Diagram Not to Scale

Elevation:	20 Feet AMSL		
Position:	38° 18' South 144° 22' East Magnetic VAR 11°E		
Radio:	CTAF 119.0 MEL CENTRE 120.0		
Strip Directions:	18/36	Western Grass	09/27 13/31 Emergency Only
Strip Lengths:	1100m	1100m	450m 600m
Strip Surface:	All cambered grass. 18/36 level. 27/09 1% up to west.		
Strip Markers:	18/36 white drums, 27/09 white drums		
Office/Contact:	Phone:0447 615100 or 0448 096066 Email: fly@tigermothworld.com.au		
Fuel:	AV-GAS, JET A1. Available through Australian Skydive Phone: 0401809022. Office hours only.		
Facilities:	Toilets at front & rear of hangar Local Taxi 131 008		
Landing Fees:		Private	Commercial O/Nite Parking
<i>Payable prior to or on arrival by cash, online or ccard. NO invoices.</i>	RAA/Ultralight	\$10	\$15 \$10/night
	Aircraft - Single OR Sml Helicopter (up to 4 seats)	15	25 \$10/night
	Aircraft - Single/Twin (up to 6 seats)	30	40 \$10/night
	Aircraft - Twin (8 or more seats) OR Turbine A/C	50	60 \$10/night
	Large Helicopter (5 or more seats)	40	50 \$10/night

WARNING: Tandem skydive operations most days from up to FL150. Dropzone up to 3nm radius around airport. Aerobatic flights conducted most days. Will occur up to 4500' in vicinity of airport.

Remarks:	<p>Prior permission required to use. Pilots should check serviceability before use. Please be sensible when visiting and show some airmanship... (some what?!) No circuit training, touch and go's or precautionary searches. Avoid overflying airport, surrounding houses & surrounding townships of Torquay and Breamlea. Powerlines and trees on approaches to RWY 18, 09 and 27. After heavy rain some areas may be soft/unusable. Kangaroos graze in adjacent wetlands and may be on runways, particularly around dawn/dusk. Birdlife around wetlands/airport can be considerable.</p>
-----------------	--

YTQY - Torquay Airport

325 Blackgate Rd. Torquay

18 / 36	All circuits to East of airport.
27 / 09	Standard left hand circuits.
13 / 31	Not available for public use. (Emergency use only) Standard left hand circuits.
Western Grass	All circuits to West of airport.
Remarks:	Please be sensible when visiting Torquay. Common sense and a little airmanship will avoid most problems and keep noise to a minimum. Avoid overflying houses in the circuit area or surrounding townships. Joining the circuit on downwind, base or straight-in is preferred. Only taxi and manoeuvre on marked runways and taxiways. Serviceability of other areas cannot be guaranteed.

